

Thank you for purchasing an Accusound Sound Hole Clip Microphone System for Guitar (Omni-Directional). (AC-CO-10)

Please try the mic in a variety of positions, we recommend placement at the top of the sound hole next to the fret board as a good starting point, but optimum positioning depends on the instrument and individual preference.

The microphone is not directional i.e. picks up from all directions so directional placement is not vitally important.

The wire can then be plugged into the rectangular power unit, which in turn can be placed on a belt or in a pocket.

If you are using a mixer desk with phantom power provision, no battery should be inserted into the power unit and the switch may be left in the "off" position. Using a standard microphone cable, the unit should then be connected to the microphone input of your desk.

If your system does not provide phantom power, please insert the battery and ensure that the unit is switched on.

The three switch positions are:

- a) "off"
- b) "on" providing a flat (natural) frequency response (indicated by a straight line).
- c) "on" providing a bass roll off facility (indicated by a bent line).

Any additional cables can be supplied in standard lengths of 2, 5 and 10 metres. (Other lengths are available on request). When placing an order, please specify length and type of connectors required.