

**Thank you for purchasing an Accusound Flexible Neck Omni-Directional Microphone System for Concertina. (AC-FO-08)**

To fit the microphone, fix the disc of dual lock on the top of the concertina (peel off the backing to reveal a self-adhesive face). The other part of the mount has two small metal clips. Push the dual lock side of this onto the disc of dual lock you have fixed to the instrument. Place the cable end of the long microphone in the two clips and bend the microphone so the right-angled microphone end is pointing to one side of the instrument about equal distance from all notes.

Repeat the above for the other side mic.

The two cables, which are fixed in to one connector, should be plugged into the rectangular power unit, which in turn can be placed on a belt or in a pocket. The power adaptor should then be connected to your amplifier or mixer using a standard microphone XLR cable. The power unit may be powered by an internal AA battery or phantom power if it is available.

If you wish to have two signals, one from each microphone for a sound engineer to adjust, then contact Accusound for optional power adaptors, one for each mic. You will need to return the microphones for to be adapted. Similarly, if you prefer the cables to be shortened, please contact Accusound.