

Thank you for purchasing an Accusound Flexible Neck Omni-Directional Chanter Microphone, 3 Drone System for Pipes. (AC-FO-12-3)

Attach the mount to the chanter of your pipes using the band provided.
Attach the wider part of the mic neck at the cable end, to the two clips on the mount.

Please try the mics in a variety of positions, optimum positioning depends on the instrument and the subjective nature of sound. Don't be afraid to experiment, the neck is flexible and will not be damaged by any reasonable manipulation and the mic can easily be unclipped for repositioning. The three slim mics are for the drones and are connected together in to one plug. The mic with the right-angle is for the chanter.

Use of the windshield is optional but if required is more conveniently fitted before placing the mic in position.

The wire can then be plugged into the dual mixer power unit, or wireless transmitter.

If you are using a mixer desk with phantom power provision, no battery should be inserted into the power unit. The rotary volume controls on the side of the mixer will balance the drones and chanter sound. Using a standard microphone cable, the unit should then be connected to the microphone input of your desk.