

**Thank you for purchasing an Accusound Contact Microphone System for Viola.  
(AC-LC-02)**

Fit the Contact (strip) microphone on the body of the violin just below the string ends under the tail piece. Squeeze the foam between the strip and the tail piece to ensure the strip is held securely. (The foam may be trimmed with scissors or a craft knife)

The strip should be mounted so that the cable exits towards the tailpiece button.

Long cable (approx. 2 m) version: secure the cable to the tailpiece by the attached Velcro fastener.

Although fitting can be easily reversed to remove the equipment, the system is designed as a semi-permanent installation and can be left in situ. It will not adversely affect the instrument in any way.

The cable can then be plugged into the rectangular power unit, which in turn can be placed on a belt or in a pocket.

If you are using a mixer desk with phantom power provision, no battery should be inserted into the power unit and the switch may be left in the "off" position.

If your system does not provide phantom power, please insert the battery and ensure that the unit is switched on.

The three switch positions are:

- a) "off"
- b) "on" providing a flat (natural) frequency response (indicated by a straight line).
- c) "on" providing a bass roll off facility (indicated by a bent line).

Using a standard microphone cable, the unit should then be connected to the microphone input of your desk.