

Thank you for purchasing an Accusound Contact Microphone System for Piano. (AC-SC-05)

To fit the Contact (strip) microphone:

Use the tape to stick the **whole** length of the paler side of the contact mic on to the soundboard of the piano, on the opposite side from the strings. Please experiment with positioning until optimum sound is achieved.

The mic can then be plugged into the power adaptor. If you are using a mixer desk with phantom power provision, no battery should be inserted into the power unit. and the switch may be left in the " off" position..

If your system does not provide phantom power, please insert the battery and ensure that the unit is switched on.

The three-position switch is

- a) "off"
- b) "on" providing a flat (natural) frequency response (indicated by a straight line)
- c) "on" providing a bass roll off facility. (Indicated by a bent line)

Using a standard microphone cable, the unit should then be connected to the microphone input of your desk.

Any additional cables can be supplied in standard lengths of 2, 5 and 10 metres. (Other lengths are available on request). When placing an order, please specify length and type of connectors required.