

**Thank you for purchasing an Accusound Flexible Neck Hyper Cardioid Microphone System for Accordion. (AC-FD-07)**

To fit the microphone, fix the disc of dual lock on the top of the accordion (peel off the backing to reveal a self-adhesive face. The other part of the mount has two small metal clips. Push the dual lock side of this onto the disc of dual lock you have fixed to the instrument. Place the cable end of the long microphone in the two clips and bend the microphone so the right-angled microphone end is pointing to the treble side of the instrument about equal distance from all notes.

Repeat the above for the bass mic.

The two cables should be plugged into the rectangular power unit, which in turn can be placed on a belt or in a pocket. Each microphone has its own volume control. The power unit may be powered by an internal 9v battery or phantom power if it is available.

If you wish to have two signals, one from each microphone for the sound engineer to adjust, then use the cylindrical power adaptors (available separately), one for each mic, in place of the rectangular unit. These require phantom power.

Other products available from Accusound include:

Combined system (contact mic and capsule mic with dual input mixer)

Wireless radio systems.