

**Thank you for purchasing an Accusound Combined (Contact & Capsule) Microphone System for Viola. (AC-LC-SD-02)**

Please take time to familiarise yourself with the system. We hope these fitting instructions are clear but please contact us if you require any clarification

**To fit the Contact (strip) microphone:** Fit the Contact (strip) microphone on the body of the violin just below the string ends under the tail piece. Squeeze the foam between the strip and the tail piece to ensure the strip is held securely. (The foam may be trimmed with scissors or a craft knife)

The strip should be mounted so that the cable exits towards the tailpiece button.

**To fit the suspension capsule microphone:** Place the foam mounting containing the microphone between the centre strings parallel to them with the shoulders touching the strings. Twist the mount so that the mic is pointing towards the bridge and the strings grip the mount firmly. Experiment with the positioning of the mount but do not allow the mic to touch the bridge.

The padded Velcro tie should then be used to hold the wire in place under the tailpiece. This helps to prevent any movement of the microphone itself during use or connection and disconnection of the system.

Use of the windshield is optional but if required is more conveniently fitted before placing the mic in position.

The contact mic and a capsule mic should then be plugged into the mixer unit.

Using a standard microphone cable, the unit should then be connected to the microphone input of your desk.

Other products available from Accusound include:

Wireless radio systems.